



(RE-)COATING OF MARINEDECK® interior

(Re-)coating

Clean the floor thoroughly using a brush or a brushing machine with a non chemical industrial cleansing agent. Carefully follow the instructions at the pack being provided by the manufacturer. Use a mop to remove excess water and dirt. Be sure all pollution and dirt is removed. To remove remainders of chewing gum, carefully use turpentine. Remove the residue from turpentine by using undiluted Cleaner

Then proceed sanding the entire deck thoroughly, using an orbital sanding machine (soft pad) with sand paper grit 120/150. Around corners, edges and seating it should be done by hand. The sanding process allows maximum adhesion of the new coat to the original coating. Vacuum any dust off the deck before coating. Now proceed to apply two coats of top coat PU 102 / satin or mat with the prescribed roller in cross layers. Apply the new top coat PU102 satin or mat as per instructions in the chapter coating in the installation instructions of MARINEDECK® interior, the concerning product data sheet and on the label at the pack. Be sure the entire surface is coated twice properly and completely.

The above advises are the best advises being available at this moment and only serve the purpose of service to our customers. The advise is based upon the recommendations in general by manufacturers of the concerning products. Maintenance procedures may change in the future, due to further testing and (new) product improvements. We strongly advise to carefully follow the instructions at the pack, being provided by the manufacturers. Avoid cleaners being branchless or not being classified. Coating, re-coating and maintenance is strictly excluded from any warranty.

Repairs

MARINEDECK® interior is easy to repair if required. The damaged planking and marine strip can be cut out and replaced with new materials.

Apply the new planks to the deck with the prescribed adhesive, marine strip and primer as per the application manual. The new planks will fade to match the existing deck over time. Please contact your distributor for more details if required.

The new planks should be coated with one coat of top coat PU102 / satin or mat after sanding and cleaning. Leave for 24 hours to cure. Then the area around the repair, including the new planks should be cleaned and lightly sanded with 150 grit sandpaper. Vacuum any dust off the deck prior to coating. Apply the second coat of top coat PU102 / satin or mat to the new planks and the area around the repair that has been sanded. The colour difference and strength of the new coating can be improved by sanding and coating the entire deck, not just the damaged area. This process is recommended where possible.

DURABLE MARINE FLOORS BY NATURE

ECOLOGICAL EXCELLENCE